


INSTALLATION INSTRUCTIONS

RH Sensor Replacement Outside Air Transmitters



IMPORTANT HANDLING PRECAUTIONS:

RH Sensors are composed of a polymer material that is prone to contamination by vapors from soldering, solvents, and outgassing of tapes and glues. Care must be taken to prevent sensor exposure to contaminants. Exposure to dust from sanding or grinding must also be avoided. Store sensor in factory packaging until time of installation.

IMPORTANT WARNINGS



- Only qualified trade installers should install this product
- This product is not intended for life-safety applications
- Do not install in hazardous or classified locations
- The installer is responsible for all applicable codes
- De-energize power supply prior to installation or service

PRODUCT APPLICATION LIMITATION:

Senva products are not designed for life or safety applications. Senva products are not intended for use in critical applications such as nuclear facilities, human implantable device or life support. Senva is not liable, in whole or in part, for any claims or damages arising from such uses.

INSTALLATION

1. Power transmitter OFF before replacing sensor.
2. Loosen lid screws to remove cover.
3. Unplug ribbon cable connector from circuit board.
4. Gently remove sensor from probe tube.
5. Carefully install new sensor.
6. Plug in ribbon cable connector.
7. Replace cover and re-power sensor.



SETUP

In normal operation, display toggles between RH% and Temp.

Press MENU button to select parameter to set:

Temp units	°F or °C
RH offset*	-5 to 5% RH in 0.1% RH increments
Temp offset	-5 to 5° in 0.1° increments

Press INC or DEC to change value of selected parameter.
Press MENU button to move to next parameter.
Settings are saved automatically.

* See CALIBRATION section prior to making adjustments to RH offset.

SPECIFICATIONS

Power supply	3-wire voltage mode (0-5v/10v) 2-wire current mode (4-20mA)	12-30vdc/24vac ⁽¹⁾ , 15mA max. 12-30vdc, 30mA max.
Outputs	RH and Temperature (option)	3-wire 0-5v/10v or 2-wire 4-20mA (selectable)
Output scaling	RH	0-100%RH
	Temperature (jumper selectable)	32-122°F (0-50°C) or -40-140 °F (-40-60°C)
Thermistor/RTD options		See ordering table
Media filter		Sintered stainless steel
Relative Humidity	Accuracy	2% models, +/-2% over 10 to 90% range 3% models, +/-3% over 20 to 80% range
	Resolution	0.05%RH
	Hysteresis	+/-1%RH
	Non-linearity	Factory linearized <1%RH
	Temperature coefficient	Fully compensated by on-board sensor
	Response time ⁽²⁾	30s
	Output update rate	2s
	Operating range	0 to 100%RH
	Long term drift	<0.5%RH per year
	Operating conditions ⁽³⁾	-20 to 60°C @ RH >90% -20 to 80°C @ RH = 50%
Temperature	Accuracy, (-20 to 70°C range)	2% models, <+/-1°C; 0.5°C typ@25°C 3% models, <+/-2°C; 0.5°C typ@25°C
	Resolution	0.01°C
	Repeatability	+/-0.1°C
	Response time ⁽²⁾	30s
	Output update rate	2s
Operating range		-40 to 120°C (sensor only)

(1) One side of transformer secondary is connected to signal common. Dedicated transformer is recommended.

(2) Time for reaching 63% of reading at 25°C and 1 m/s airflow.

(3) Long term exposures to conditions outside normal range or high humidity may temporarily offset the RH reading (+3%RH after 60 hours.)

TROUBLESHOOTING

Symptom	Solution
No output	Check wiring. Ensure power supply meets requirements.
Temp or RH reading error	Verify control panel software is configured for correct output scaling.
	Verify accuracy of test instrument. Observe installation and calibration guidelines
	Verify unit is securely installed on duct without excessive air leakage.
	Perform calibration only if necessary.
Sensor damage, contamination, or long-term drift	Replace sensor element. Consult factory for ordering information.

CALIBRATION

Senva RH sensors are factory calibrated to NIST traceable standards. No field calibration is necessary or recommended. However, to facilitate compliance with job requirements and commissioning procedures, provisions for field calibration are provided:

1. Locate calibration instrument and sensor in close proximity to each other in a controlled environment free of drafts, people, and equipment to reduce influence on RH and temperature.
2. Compare reading of sensor to calibration instrument, and note difference.
3. Refer to SETUP section to change RH offset as needed. Set RH offset to zero to restore factory calibration.

NOTE: In case of damage, contamination, or long-term drift, sensor element may be replaced. Consult factory for ordering information and instructions.