

INSTALLATION INSTRUCTIONS

PW30 & PW30 w/ Bypass Manifold Wet-Wet Pressure Transmitter



IMPORTANT WARNINGS

- Only qualified trade installers should install this product
- This product is not intended for life-safety applications
- Do not install in hazardous or classified locations
- The installer is responsible for all applicable codes
- De-energize power supply prior to installation or service

PRODUCT APPLICATION LIMITATION:

Senva products are not designed for life or safety applications. Senva products are not intended for use in critical applications such as nuclear facilities, human implantable device or life support. Senva is not liable, in whole or in part, for any claims or damages arising from such uses.

IMPORTANT!

- Do NOT exceed gauge pressure rating of sensor.
- Use ONLY Senva gauge pressure sensors provided with your PW transmitter to obtain the specified transmitter accuracy.
- Follow instructions step by step to ensure proper setup.

INSTALLATION

For PW30 with bypass assembly:

1. To complete assembly plug PWT connector into respective PWT sensor. Sensor A goes to high side pressure and Sensor B goes to Low side pressure. Sensor A and B labels are found on the board of the PW30.

2. **IMPORTANT** :For complete weather rating the Rubber gasket shown in the image at the bottom of the page must be installed.

1. Identify PWT and their respective PSIG rating.

If the expected system gauge pressure exceeds the PSIG rating on the PWT sensors call factory and DO NOT proceed with install.

Max PSIG Rating

Sensor PSI Rating: PWT

Maximum PSIG Rating

025 = 25 PSIG
050 = 50 PSIG
100 = 100 PSIG
250 = 250 PSIG
500 = 500 PSIG

2. Plumb PWT sensors to media. Plumb PWT sensors to the side or top of pipe, as plumbing to the bottom will cause sediment to settle and could clog or affect sensor accuracy. **It is advisable to use a single wrap of PTFE tape on the PWT sensors threads, or other thread sealing alternative, to improve sensor accuracy.**

No bypass valve manifold is necessary. Use only Senva gauge pressure sensor elements provided with your transmitter.

Optional shutoff valves are available - Senva recommends closing service valves when flushing system to prevent containments and water hammer from damaging PWT sensing elements.

4. Run the appropriate length cables between the PW transmitter and PWT sensors.

Senva recommends 22AWG stranded, 3 conductor shielded cable to wire between the PW transmitter and PWT sensors.


5. Loosen the top screw on each PWT sensor and remove the terminal block for wiring as shown below:

Conduit Adapter Terminal Block Rubber Gasket PWT Element



6. Run the cable through the conduit adapter and connect the wires to the PWT terminal block. Note that the conduit terminal block is numbered and color coded to match the terminal label colors on the PW transmitter.

IMPORTANT: DO NOT connect the shield at the PWT sensor element end. The shielding should only be connected to the ground terminal at the PW transmitter end.




Pin	Connection	Color
1	PWR	Red
2	GND	Green
3	Signal (S1/S2)	White
⏏	Shield	Black

7. Reassemble the PWT conduit adapter and terminal block. Place the rubber cover back on the conduit adapter and plug the adapter onto the PWT sensor. Tighten the assembly screw.

DO NOT attempt to plumb or tighten the PWT sensors while wires are attached, as you run the risk of pulling wires from cable attachments.


8. Wire PWT sensors to the PW Transmitter terminals labeled A & B, for high and low side pressure respectively. See above table if wiring a pre ordered cable length for color coordination. For strain relief, tighten cable glands.




IMPORTANT: Shielding should be connected to the shield (GND) Terminal at the PW transmitter end, and left unconnected at the PWT sensor element end.

9. Connect conduit fittings to the PWT sensors and PW transmitter. Use water tight fittings if required by your installation conditions.

10. Select 20mA, 5V or 10V output using OUTPUT switch based on wiring configuration.



11. Wire PW transmitter for voltage or current output as shown (Remote zero wiring is optional):



12. Configure output range and sensor PSIG using DIP switches 1-7. DIP 1-3 set the sensor PSIG corresponding to the PWT ordered. DIP 4-7 are used to set the desired output signal range. Both use the binary code system outlined in the table.

PW Transmitter DIP Switch Configuration:

DIP Switch Settings




DIP	Function	LEFT	RIGHT
1	SENSOR2	0 (off)	1 (on)
2	SENSOR1	0	1
3	SENSOR0	0	1
4	RANGE3	0	1
5	RANGE2	0	1
6	RANGE1	0	1
7	RANGE0	0	1
8	Units	KPA	PSI
9	UNI/BI	BI	UNI
10	MODE	FAST	SLOW
11	SWAP	B-A	A-B
12	ABS	ABS	+/-

DIP	Binary	SENSOR (PSIG)
1-3	000	TEST
	001	15*
	010	25*
	011	50
	100	100
	101	200*
	110	250
	111	500
DIP	Binary	RANGE (PSID)
4-7	0000	0-1
	0001	0-2
	0010	0-5
	0011	0-10
	0100	0-15
	0101	0-20
	0110	0-25
	0111	0-30
	1000	0-40
	1001	0-50
	1010	0-75
	1011	0-100
	1100	0-125
	1101	0-150
	1110	0-250
	1111	0-500

*15, 25 and 200 PSIG sensors are not offered by senva.

Example:



13. Inspect LCD for readings. LCD toggles between sensor A reading, sensor B reading, and PSID reading.

Sensor A reading is indicated by a tick mark on the top left of LCD. Sensor B reading is indicated by a tick mark at the bottom left of LCD. PSID reading is displayed without any mark at the left of the LCD.

O/R symbol will flash in bottom center of LCD if differential pressure reading is over range. If this occurs, select larger PSID range to avoid clipping of readings.

14. Check remaining DIP switch (8-12) configurations for additional setup options:

Units: LCD will display readings in PSI or kPa. LCD will indicate PSI or kPa at top of screen.

UNI/BI: PW transmitter can be setup in Uni or Bi directional mode.

Bi-Directional Mode Example range set at 100 PSID:

A	B	DP	OUTPUT
100	0	+100	20mA/10V/5V
100	50	+50	16mA/7.5V/3.75V
50	50	0	12mA/5V/2.5V
50	100	-50	8mA/2.5V/1.25V
0	100	-100	4mA/0V/0V

MODE: In 'Slow Mode' the output returns a reading averaged over 64 samples. In 'Fast Mode' the output returns the most recently calculated reading for PSI.

SWAP: If PWT sensor A was plumbed to the return (low) side and PWT sensor B was plumbed to the supply (high) side instead of re-plumbing the sensors, the Port Swap can be utilized without a physical reconfiguration.

ABS: In Absolute Mode, values will always be reported positive.

15. To custom zero the device (optional), hold down the zero button for 5 seconds (until the LCD blinks once). Hold down for 10 seconds (until LCD blinks twice) to reset/clear the zero value.


16. Seal remaining conduit knockouts on PW transmitter.

SENVA TECHNICAL SUPPORT


Need further assistance? Call our toll-free number for live technical support: (866) 660-8864 or feel free to email us at support@senvainc.com

DIMENSIONS


PW30W



PW30M



PW30AW/M



SPECIFICATIONS

Power supply	Voltage output mode (0-5v)	12-30VDC/24VAC ⁽¹⁾ , 20mA max.	
	Voltage output mode (0-10v)	13-30VDC/24VAC required for 10V FS output	
	Current (4-20mA) output mode	15-30VDC(0 ohm)/16-30VDC (250 Ohm)/ 18-30VDC (500 Ohm) , 20mA max.	
Outputs	Switch selectable	2-wire 4-20mA, 3-wire 0-5V/10V	
Operating Temperature	Transmitter	-22 to 158°F (-30 to 70C)	
Media Compatibility	Type	Water, other 316 SS compatible media (316L diaphragm)	
	Temperature	32 to 250°F (0-125°C)	
Zero adjustment	Automatic	Pushbutton, Remote zero	
		Press button for 5 seconds to re-zero	
		Hold for 10 seconds to restore factory settings	
Sensor Type		Micro-machined silicon strain gauge	
PW Transmitter Accuracy ⁽²⁾	Sensor PSIG	2% Accurate ranges	1% Accurate ranges
	25	0-1 / 0-2 PSID	0-5 / 0-10 / 0-15 / 0-20 / 0-25 PSID
	50	0-10 / 0-15 PSID	0-20 / 0-25 / 0-30 / 0-40 / 0-50 PSID
	100	0-15 / 0-20 / 0-25 / 0-30 PSID	0-40 / 0-50 / 0-75 / 0-100 PSID
	250	0-30 / 0-40 / 0-50 PSID	0-75 / 0-100 / 0-125 / 0-150 / 0-250 PSID
Range according to PSID table in PW Transmitter DIP Switch Configuration table	500	0-75 / 0-100 / 0-125 PSID	0-150 / 0-250 / 0-500 PSID
	Accuracy	< +/-0.25% BFSL	
	Stability (1 year)	+/-0.2% FS, typ	
	Over-range protection	200% rated pressure	
	Pressure Cycles	> 100 Million	
	Compensated Range	14 to 158°F (-10-70°C)	
	Temperature Compensation %FS/C	Zero, <+/-0.03(<100kPa), <+/-0.02(>100kPa) Span, <+/-0.03(<100kPa), <+/-0.02(>100kPa)	
Sensor Performance	Vibration	10G peak, 20 to 2000 Hz.	
	Construction	Powder coated steel	
	Rating	NEMA 3R	
	Construction	PC/ABS	
	Rating	NEMA 4X	
Enclosure, PW30M	Construction	Stainless Steel, 304, 1/4" MNPT, PG9 Conduit Fitting	
Enclosure, PW30W	Construction		
Enclosure, PWT[xxx] Sensor	Construction		

(1)One side of transformer secondary is connected to signal common. Dedicated transformer is recommended.

(2)Because of lower accuracy, it is not factory recommended to use an output range less than 10% of the total sensor PSIG.

TROUBLESHOOTING

Symptom	Solution
No output	Check wiring. Ensure power supply meets requirements
Pressure reading error	Verify control panel software is configured for correct output scaling
	Verify switch and jumper settings
Device will not zero	Hold ZERO button for full 5-seconds until LCD blinks once
	Continue holding ZERO button for 10-15 seconds, until LCD blinks twice, to restore factory settings